



## Nokia Spy Phone Instructions

Insert sim card & charge phone before use.

When you turn the phone on if the word 'spy' appears on the screen then just press \* for 3 seconds followed by zero. If the word 'spy' doesn't appear go to the menu, then profiles, and then choose 'spy' as your profile, then press \* for 3 seconds followed by zero. The display should disappear and the phone will be in 'spy' mode, if you try ringing it, it should auto-answer with no lights or sound.

To return the phone to normal use go to the menu and then profiles and then choose 'general'. The phone can then be used as any other, and will appear completely normal.

If you forgot the number of the pre-pay sim you inserted, then just type in; \*#100# then send.

Although the spyphone will silently auto-answer and has no display, sounds or lights in spy mode, it will make the characteristic cell-phone buzz if left within a couple of feet of a regular landline phone or stereo system – both when it polls the cell mast & when you're listening in. Please bear this in mind when positioning the phone.

You can track the whereabouts of the phone by registering with a cell tracking service such as '<http://www.mobilelocate.co.uk/>'. Vodafone is the most accurate network for tracking. Positioning can be as good as 50 metres in town and down to around 500 metres in a rural situation. O2, Orange & t-mobile aren't as good. Still, it's cheap and gives you a good idea if you're being lied to!

We can also supply GPS tracking devices with an accuracy of several metres. They start at £195.

Thanks for your business.

[www.spystore.co.uk](http://www.spystore.co.uk)

0870 2255 886